

## 1246 MH AV Instructions

This room has Zoom Room functionality built-in. There is an HDMI input at the base of the wall as well as wireless sharing available through Zoom. The display is **interactive** so all control is by touching the screen.

1. Turn on the display using the **power button on the display**.
2. **Touch the interactive display** to select what you'd like to do. You can start a scheduled meeting, create a new meeting.



3. **To wirelessly share** touch **Share Content** on the display and follow the instructions. You will use Screen Sharing in the Zoom app on your computer.
4. **To share using HDMI**, simply plug in to the HDMI cable.

Please contact BioSci Computing at [bcshelp@uci.edu](mailto:bcshelp@uci.edu), 824-3555, with any AV questions.