



## UCI Steinhaus 351 User Guide



1 **ON**-Press this button to power on the display.


2 **OFF**-Press this button to power off the display.

A  **Power**-This button will also power on and off the display. If the display is off this button will turn the display on. If the display is on this button will turn the display off.

4 **HDMI**-Press this button to select the HDMI input. Use the provided HDMI cable and HDMI wall-plate directly underneath the display.

5 **APPLE**-Press this button to select the Apple TV input. Use the provided Apple TV remote to control the Apple TV or connect with a Apple laptop.

6 **Volume Control**-Use this dial to increase or decrease the audio volume in the room. A blue LED will indicate the increase or decrease. Audio is sensitive, be sure to adjust accordingly.

7  **Mute**-Use this button to mute the audio in the room. The blue LED around the volume dial will disappear and the "mute" button will illuminate blue to indicate mute.

**Questions? Please see Kate Fuentes in the EcoEvo Office, 321 Steinhaus, 824-6006**