


1201 MH AV Instructions

This room has Zoom Room functionality built-in. There is an HDMI input in the table cubby as well as wireless sharing available through Zoom. The display is **interactive** so all control is by touching the screen.

1. Turn on the display using the **power button on the display (or remote)**.
2. **Touch the interactive display** to select what you'd like to do. You can start a scheduled meeting, create a new meeting, etc.



3. **To wirelessly share** touch **Share Content** on the display and follow the instructions. You will use Screen Sharing in the Zoom app on your computer.
4. **To share using HDMI**, simply plug in to the HDMI cable and tap the Share Content button on the display.

Please contact BioSci Computing at bcshelp@uci.edu, 824-3555, with any AV questions.